



LYTEPOD ASSEMBLY GUIDE

All our user guides are compiled in order to give the user step by step instructions to ensure the product is assembled correctly and to the latest safety standard for use when working at height.

The law requires that anyone assembling and using a podium be competent to do so and should also have a copy of the correct manufacturer's instructions.

If you require further information on this, please call us on **0370 99 00 999**.



STEP ONE



Unfold Podium and attach the brace bar provided to the vertical tubing at the back of the podium as shown.

STEP TWO



Attach the ladder frame to the front of the podium ensuring that all of the brace claws are locked into position. The ladder can be used to help square the podium.

STEP THREE



Attach the platform to the front of the podium ensuring that all of the brace claws are locked into position.

STEP FOUR



Attach stabilisers to the vertical tubing at the back of the podium as shown in the image.

OPTIONAL TOEBOARD FITTING



Attach toeboards to the platform as shown in the image. The podium is now ready to be safely used.

